

TOOLS NEEDED:

1/16 Drill Bit

Phillips Screwdriver

Tape Measure



Porch Valance Installation Instructions - Costa Track

1. Mark level line across for track placement.
2. For Track without Flange- Screw track onto ceiling using the provided #4 Flathead screws into the predrilled holes.
3. For Track with Flange- Drill pilot holes in flange of track. Start 1" from each end and measure evenly 12" - 15" apart. Use 3/16" drill bit for pilot holes. Screw track onto wall or ceiling using the provided # 8 Panhead screws.

Track Without Flange



Track With Flange



4. Slide one end of the beading insert sewn on the top of the valance into the track, from the side of the track or using the notch as shown below.

If the track has been cut for shipping, simply continue with the next piece of track. The piece of track with the 4" opening can be placed in the position of your choice.

Questions? Call PYC Awnings 1-800-933-6936



If you can not slide the valance in from the side of the track, use the center notch to slide in the valance.